

8'-30000 Double-Wall Compartment Tank Extension 30015 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
0.5	21	30.5	2390	60.5	6267	90.5	10844	120.5	15710
1.0	34	31.0	2446	61.0	6339	91.0	10924	121.0	15791
1.5	50	31.5	2502	61.5	6411	91.5	11003	121.5	15873
2.0	66	32.0	2558	62.0	6483	92.0	11083	122.0	15954
2.5	85	32.5	2615	62.5	6555	92.5	11163	122.5	16036
3.0	105	33.0	2672	63.0	6628	93.0	11243	123.0	16117
3.5	126	33.5	2730	63.5	6701	93.5	11323	123.5	16199
4.0	149	34.0	2788	64.0	6774	94.0	11403	124.0	16280
4.5	172	34.5	2846	64.5	6847	94.5	11484	124.5	16362
5.0	197	35.0	2905	65.0	6920	95.0	11564	125.0	16443
5.5	223	35.5	2964	65.5	6994	95.5	11644	125.5	16525
6.0	250	36.0	3023	66.0	7068	96.0	11725	126.0	16606
6.5	278	36.5	3083	66.5	7141	96.5	11805	126.5	16688
7.0	307	37.0	3143	67.0	7215	97.0	11886	127.0	16769
7.5	337	37.5	3203	67.5	7290	97.5	11966	127.5	16850
8.0	367	38.0	3263	68.0	7364	98.0	12047	128.0	16931
8.5	399	38.5	3324	68.5	7438	98.5	12128	128.5	17013
9.0	431	39.0	3385	69.0	7513	99.0	12208	129.0	17094
9.5	464	39.5	3447	69.5	7588	99.5	12289	129.5	17175
10.0	498	40.0	3509	70.0	7663	100.0	12370	130.0	17256
10.5	533	40.5	3571	70.5	7738	100.5	12451	130.5	17337
11.0	568	41.0	3633	71.0	7813	101.0	12532	131.0	17418
11.5	604	41.5	3696	71.5	7888	101.5	12613	131.5	17499
12.0	641	42.0	3759	72.0	7964	102.0	12694	132.0	17580
12.5	678	42.5	3822	72.5	8040	102.5	12775	132.5	17661
13.0	716	43.0	3886	73.0	8116	103.0	12856	133.0	17742
13.5	755	43.5	3950	73.5	8191	103.5	12937	133.5	17823
14.0	795	44.0	4014	74.0	8268	104.0	13018	134.0	17903
14.5	835	44.5	4078	74.5	8344	104.5	13100	134.5	17984
15.0	875	45.0	4143	75.0	8420	105.0	13181	135.0	18065
15.5	917	45.5	4208	75.5	8497	105.5	13262	135.5	18145
16.0	958	46.0	4273	76.0	8573	106.0	13344	136.0	18226
16.5	1001	46.5	4338	76.5	8650	106.5	13425	136.5	18306
17.0	1044	47.0	4404	77.0	8727	107.0	13506	137.0	18387
17.5	1087	47.5	4470	77.5	8804	107.5	13588	137.5	18467
18.0	1132	48.0	4536	78.0	8881	108.0	13669	138.0	18547
18.5	1176	48.5	4603	78.5	8958	108.5	13751	138.5	18627
19.0	1221	49.0	4670	79.0	9036	109.0	13832	139.0	18708
19.5	1267	49.5	4737	79.5	9113	109.5	13914	139.5	18788
20.0	1313	50.0	4804	80.0	9191	110.0	13995	140.0	18868
20.5	1360	50.5	4871	80.5	9268	110.5	14077	140.5	18948
21.0	1407	51.0	4939	81.0	9346	111.0	14158	141.0	19027
21.5	1455	51.5	5007	81.5	9424	111.5	14240	141.5	19107
22.0	1503	52.0	5075	82.0	9502	112.0	14322	142.0	19187
22.5	1552	52.5	5143	82.5	9580	112.5	14403	142.5	19266
23.0	1601	53.0	5212	83.0	9659	113.0	14485	143.0	19346
23.5	1651	53.5	5281	83.5	9737	113.5	14566	143.5	19425
24.0	1701	54.0	5350	84.0	9815	114.0	14648	144.0	19505
24.5	1751	54.5	5419	84.5	9894	114.5	14730	144.5	19584
25.0	1802	55.0	5489	85.0	9973	115.0	14811	145.0	19663
25.5	1853	55.5	5558	85.5	10051	115.5	14893	145.5	19742
26.0	1905	56.0	5628	86.0	10130	116.0	14975	146.0	19821
26.5	1957	56.5	5698	86.5	10209	116.5	15056	146.5	19900
27.0	2010	57.0	5769	87.0	10288	117.0	15138	147.0	19979
27.5	2063	57.5	5839	87.5	10367	117.5	15220	147.5	20058
28.0	2117	58.0	5910	88.0	10447	118.0	15301	148.0	20137
28.5	2170	58.5	5981	88.5	10526	118.5	15383	148.5	20215
29.0	2225	59.0	6052	89.0	10605	119.0	15465	149.0	20294
29.5	2279	59.5	6123	89.5	10685	119.5	15546	149.5	20372

**8'-30000 Double-Wall Compartment Tank Extension
30015 (liters)**

30.0	2334	60.0	6195	90.0	10764	120.0	15628	150.0	20450
------	------	------	------	------	-------	-------	-------	-------	-------

8'-30000 Double-Wall Compartment Tank Extension

30015 (liters)

Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)	Liquid Depth (cm)	Volume (liters)
150.5	20528	180.5	24954	210.5	28522
151.0	20606	181.0	25022	211.0	28570
151.5	20684	181.5	25090	211.5	28618
152.0	20762	182.0	25158	212.0	28665
152.5	20840	182.5	25225	212.5	28712
153.0	20917	183.0	25292	213.0	28758
153.5	20995	183.5	25359	213.5	28803
154.0	21072	184.0	25426	214.0	28848
154.5	21149	184.5	25492	214.5	28893
155.0	21226	185.0	25558	215.0	28937
155.5	21303	185.5	25624	215.5	28981
156.0	21380	186.0	25690	216.0	29023
156.5	21457	186.5	25755	216.5	29066
157.0	21534	187.0	25820	217.0	29108
157.5	21610	187.5	25885	217.5	29149
158.0	21686	188.0	25950	218.0	29189
158.5	21763	188.5	26014	218.5	29229
159.0	21839	189.0	26078	219.0	29269
159.5	21915	189.5	26142	219.5	29307
160.0	21990	190.0	26206	220.0	29345
160.5	22066	190.5	26269	220.5	29383
161.0	22142	191.0	26332	221.0	29419
161.5	22217	191.5	26395	221.5	29455
162.0	22292	192.0	26457	222.0	29490
162.5	22367	192.5	26519	222.5	29525
163.0	22442	193.0	26581	223.0	29559
163.5	22517	193.5	26642	223.5	29592
164.0	22592	194.0	26703	224.0	29624
164.5	22666	194.5	26764	224.5	29655
165.0	22740	195.0	26825	225.0	29686
165.5	22814	195.5	26885	225.5	29715
166.0	22888	196.0	26945	226.0	29744
166.5	22962	196.5	27004	226.5	29772
167.0	23036	197.0	27064	227.0	29798
167.5	23109	197.5	27122	227.5	29824
168.0	23183	198.0	27181	228.0	29849
168.5	23256	198.5	27239	228.5	29872
169.0	23329	199.0	27297	229.0	29895
169.5	23402	199.5	27355	229.5	29916
170.0	23474	200.0	27412	230.0	29935
170.5	23547	200.5	27469	230.5	29954
171.0	23619	201.0	27525	231.0	29970
171.5	23691	201.5	27581	231.5	29985
172.0	23763	202.0	27637	232.0	29998
172.5	23835	202.5	27692	232.5	30008
173.0	23906	203.0	27747	233.0	30015
173.5	23977	203.5	27802		
174.0	24048	204.0	27856		
174.5	24119	204.5	27910		
175.0	24190	205.0	27963		
175.5	24261	205.5	28016		
176.0	24331	206.0	28069		
176.5	24401	206.5	28121		
177.0	24471	207.0	28172		
177.5	24540	207.5	28224		
178.0	24610	208.0	28275		
178.5	24679	208.5	28325		
179.0	24748	209.0	28375		
179.5	24817	209.5	28425		



CONTAINMENT
SOLUTIONS®

HOW TO PROPERLY GAUGE YOUR TANK:

Underground storage tanks require periodic measurement to determine current inventory level. Using the proper methods when gauging your tank's contents will insure the most accurate reading and insure that you do not damage your tank. The following procedure should be followed whenever you use a gauge stick to determine the amount of product that is in your tank:

- 1) Use a wood dipstick with a rubber or nylon tip. Metallic dipsticks are not recommended. This will insure that frequent tank gaugings or an accidental dropping of the gauge stick into the tank will not damage the tank bottom.
- 2) Slowly lower your gauge stick into the fill port until it touches the tank bottom. Never free drop the gauge stick. This can result in inaccurate measurements due to product splashing. Free dropping can also result in gauge stick damage and tank damage.
- 3) Remove your dipstick slowly and read the product level directly from the gauge stick.

Water Paste Detection:

To detect water in the tank bottom, water detection paste is available from petroleum equipment distributors. See vendor below or suitable equal.

Gasoil Water Finding Paste
Federal Process Corp.
800-846-7325
www.gasoil.com

Caution

Pressurized deliveries are not recommended. If the delivery vehicle uses pumps to fill the tank, install overfill shutoff equipment in the tank and truck to prevent the tank from being overfilled.

Overfilling the tank under pressure will damage the tank even if the tank vent is unrestricted.

Containment Solutions, Inc.
333 North Rivershire Dr., Suite 190
Conroe, TX 77304
Tel: 936-756-7731
Fax: 936-756-7766

Note: Calibration chart is based on the fluid level above a 8mm [5/16"] deflector plate.

**8'-30000 Double-Wall Compartment Tank Extension
30015 (liters)**

180.0	24886	210.0	28474			
-------	-------	-------	-------	--	--	--